


Multiple Accelera® E In Parallel Reverse Return Configuration



→ direction of flow

⏏ ball valve



NOTE: This schematic is for illustration purposes only and must not be used for actual installation without appropriate engineering and technical advice from a properly licensed professional in the locality where the installation is to be completed.